Roller blinds

Inside fit




Getting started

Being careful not to damage the blind or chain when removing the packaging, unpack the blind and check all parts are included:

- Roller blind
- 2 x universal end brackets
- 4 x screws
- 2 x ball stops
- 1x child safety tensioner with screw

Tools required:


- Pencil
- Tape measure
- Electric screwdriver
- #2 square drive



Step 1

1 x universal end bracket 2 x screws


Decide how far back in the sill you want your blind to sit and fix one universal end bracket inside the window frame in the top left hand corner of the window using two of the screws provided.



Step 2

1 x universal end bracket 2 x screws

Repeat step 2 on the right side of the window measuring the same distance back from the front of the frame.




Step 3

Lift the blind up to the window with the controls on the side selected when ordering.

Place the spring pin-end into the bracket first (the opposite end to the chain).


Tip: Always handle blinds with clean hands to avoid leaving marks or damaging the material.



Step 4


Applying pressure toward the pin end (to depress the pin), move the chain end of the blind into the bracket.

Pull down gently until the hooks set into the bracket.



Step 5

Remove the rubber band from the chain to operate the blind.




Step 6

2 x ball stops

Attaching ball stops ensures the blind is not wound up or down too far, preventing damage.

Roll the blind to the top of its range, note the position on the chain and attach a ball stop.

Roll the blind to the bottom of its range, note the position on the chain and attach a ball stop.



Step 7

1 x child safety tensioner with screw

Place the tensioner over the chain and let hang to determine its fixing position before attaching using the screws provided.

Tip: Don't pull the chain too tight, leave a little bit of give to make operating the blind easier.